



**UNTREATED CARPET**

The liquid soaks in immediately



**TREATED CARPET**

The liquid sits on the surface allowing time to be removed before it soaks in and stains

## USAGE INSTRUCTIONS

### PREPARATION

Before application of Aeroglas, ensure that the carpet is clean and dry. Applying any protector onto soiled carpets will not result in an effective coating.

### COVERAGE

The consumption of Aeroglas will depend on the thickness of the carpet pile onto which the coating is being applied. Generally one litre will coat between 5 and 15 square metres. If a carpet has a pile thickness of 4mm, it is expected that 10 SQM can be coated with one litre.

Please be sure to penetrate the first 5mm of the carpet.

### APPLICATION

Spray the coating with a hand spray bottle lightly onto the surface. Gently rub the carpet to remove trapped air bubbles within the pile while product is still wet.

Allow time to dry thoroughly before use.



## TECHNICAL DATA INFORMATION

### DESCRIPTION

AeroGlas is the world's first aerospace-approved nano-coating for aircraft carpets. Containing no fluorocarbons or silicones, only hard-wearing glass, coated carpets will preserve that "new look" longer, extending the life of the carpet.

The coating will not be removed by normal carpet extraction cleaning procedures. Ultra-thin (150 NM - 400 times thinner than a human hair) pure Glass (SiO<sub>2</sub>) coating with anti-microbial properties which helps in the reduction of cabin odours. The coating is oleophobic, hydrophobic, flexible and resistant to acids, alkali and solvents.

### FEATURES

- Easy to apply
- Long lasting
- Once applied, removal of spills is extremely easy
- Staining is reduced considerably (almost eliminated)
  - Reduces bacteria, which reduces odour

### QUALIFICATIONS

- FAR/EASA CS 25.853 Appendix F. Part 1
  - DIN EN ISO 10993 1 - 12

### MOQ

1 x 5 Litre Jerry Can, then multiples of 5 Litres thereafter

### AVAILABILITY

Ex stock Aerofloor, subject to stock remaining unsold

### CERTIFICATION

All orders will be accompanied by a C of C for traceability purposes only.

### HEALTH & SAFETY

Avoid contact with eyes and skin. If contact is made, wash areas with clean water for at least fifteen minutes.

Seek medical advice if irritation or adverse symptoms develop.

**Keep out of the reach of children.**

### IMPORTANT INFORMATION

Application of the AeroGlas does not in anyway eradicate any FR treatment that has already been applied.